

Содержание

				No. 1
1.	Обз	ор		3
2.	Ope	nVpn		4
	2.1	Устан	ювка OpenVPN (OC Windows)	4
	2.2	Созда	ние сертификатов	6
		2.2.1	Первоначальная конфигурация	6
		2.2.2	Создание сертификата СА	7
		2.2.3	Создание файла dh1024.pem	8
		2.2.4	Создание сертификата сервера	8
		2.2.5	Создание сертификата клиента	8
	2.3	Файл	ы конфигурации	8
		2.3.1	Конфигурация сервера	8
		2.3.2	Подключение к серверу OpenVPN	17
		2.3.3	Конфигурация клиента	19
		2.3.4	Создание файла client.tar	23
3.	Нас	тройка	а телефона	24
	3.1	Конф	игурация через web	24
		_		

1. Обзор

VPN (виртуальная частная сеть) - это технология, обеспечивающая защищённую (закрытую от внешнего доступа) связь логической сети поверх частной или публичной при наличии высокоскоростного интернета.

Соединение использует виртуальный туннель для реализации шифрования данных, проверки и пользователя аутентификация, которая гарантирует, что данные не были фальсифицированы, реплицированы, проверены.

Что касается выделенной линии, VPN работает в Интернете без чрезмерных затрат. Можно безопасно и экономично передавать частные данные через Интернет. VPN-система включает VPN-сервер, VPN-клиент и виртуальный туннель. На рис.1 показана простая схема VPN.



Рис.1

VPN позволяет ір телефону из общедоступной сети иметь безопасный удалённый доступ к частной сети (рис.2)





2. OpenVpn.

OpenVPN - свободная реализация технологии виртуальной частной сети (VPN) с открытым исходным кодом для создания зашифрованных каналов типа точка-точка или сервер-клиенты между компьютерами

2.1 Установка OpenVPN (OC Windows)

Загрузите и установите **OpenVPN** (например, OpenVPN 2.3.18) и выполните следующие шаги:

В данном примере, **OpenVPN** устанавливался **C:\Program Files\OpenVPN**.

- Запускаем скачанный файл - нажимаем «Next» - «I Agree»



PENVFIN	Please review the license terms 2,3,18-I602.	before installing O	penVPN
Press Page Down to see th	ne rest of the agreement.		
OpenVPN (TM) An Open	n Source VPN daemon		^
Copyright (C) 2002-2017	OpenVPN Technologies, Inc. <sale< th=""><td>s@openvpn.net></td><td></td></sale<>	s@openvpn.net>	
This distribution contains r of which fall under differen or any of the bundled com	multiple components, some nt licenses. By using OpenVPN ponents enumerated below, you conditions of the license for		
each respective componer	nt.		
openVPN trademark	nt.		•
openVPN trademark	nt. the agreement, click I Agree to co VPN 2.3.18-I602.	ntinue. You must a	↓ ccept the

- выставляем маркеры «OpenVPN RSA Certificate Management Scripts» (нужен для возможности сгенерировать сертификаты) и OpenSSL Utilities

Contract (INA. I.	Choose Components	
PENVPN	Choose which features of OpenVPN 2.3.18-I602 you wan install.	to
Select the components to in service if it is running. All DI	istall/upgrade. Stop any OpenVPN processes or the OpenVP LLs are installed locally.	N
Select components to install	I: OpenVPN GUI OpenVPN File Associations OpenSSL Utilities OpenVPN RSA Certificate Management Scripts	î
	Add Shortcuts to Start Menu	
	Add Shortcuts to Start Menu Dependencies (Advanced)	~
Space required: 6.3MB	Add Shortcuts to Start Menu Dependencies (Advanced) Description Position your mouse over a component to see its description.	~
Space required: 6.3MB	Add Shortcuts to Start Menu Dependencies (Advanced) Description Position your mouse over a component to see its description,	~

5

«Next» и «Install» — начнётся установка.

В процессе мастер установки может выдать запрос на подтверждение установки виртуального сетевого адаптера — соглашаемся (Install).

После завершения нажимаем «Next» - снимаем галочку «show Readme» - «Finish»

Установка завершена.

2.2 Создание сертификатов. 2.2.1 Первоначальная конфигурация.

- В папке установки **OpenVPN** (по умолчанию, **C:\Program Files\OpenVPN**) и создаём каталог **SSL**.
- В папке C:\Program Files\OpenVPN\easy-rsa, создаём файл vars.bat, открываем его на редактирование и приводим к следующему виду:

set "PATH=%PATH%;%ProgramFiles%\OpenVPN\bin" set HOME=%ProgramFiles%\OpenVPN\easy-rsa set OPENSSL_CONF=C:\Program Files\OpenVPN\easy-rsa\openssl-1.0.0.cnf *set KEY CONFIG=openssl-1.0.0.cnf* set KEY DIR=keys set DH KEY SIZE=1024 set KEY SIZE=1024 set KEY COUNTRY=RU set KEY_PROVINCE=Ekaterinburg set KEY_CITY=Ekaterinburg set KEY_ORG=Organization set KEY EMAIL=i.ivanov@nag.ru set KEY_CN=NAG set KEY OU=NAG set KEY NAME=server.domain.ru set PKCS11 MODULE PATH=NAG set PKCS11 PIN=12345

* в каталоге **easy-rsa** уже есть файл **vars.bat.sample** — можно переименовать и использовать его.

** значение **НОМЕ** не меняем, если оставили путь установки программы по умолчанию;

КЕҮ_DIR — каталог, куда будут генерироваться сертификаты;

KEY_CONFIG может быть разным — его лучше посмотреть в файле vars.bat.sample или по названию соответствующего файла в папке easy-rsa;

КЕҮ_NAME желательно, чтобы соответствовал полному имени VPN-сервера; остальные опции можно заполнить произвольно.

2.2.2 Создание сертификата СА.

- Запускаем командную строку (cmd) от имени администратора:



- Переходим в каталог easy-rsa:

cd C:\\Program Files\OpenVPN\easy-rsa

- Запускаем файл vars.bat

vars.bat

- Чистим каталоги от устаревшей информации:

clean-all.bat

Снова запускаем vars.bat (после clean переопределяются некоторые переменные):

vars.bat

- Генерируем сертификат и на все запросы нажимаем Enter.

build-ca.bat

2.2.3 Создание файла dh1024.pem

В командной строке (cmd) введите

build-dh

2.2.4 Создание сертификата сервера

В командной строке необходимо ввести:

build-key-server.bat cert

* где **cert** — имя сертификата; на все запросы нажимаем **Enter**. В конце подтверждаем два раза корректность информации вводом **у**.

Содержимое папки C:\Program Files\OpenVPN\easy-rsa\keys переносим в C:\Program Files\OpenVPN\ssl.

2.2.5 Создание сертификата клиента.

Генерируем сертификат пользователя, в командной строке (cmd) вводим:

build-key.bat clients

* на все запросы наживаем Enter, в конце — у.

** Мы можем на каждого клиента сгенерировать свой сертификат, а можем использовать один на всех. Первый вариант безопаснее, второй — удобнее. Каким пользоваться — решать исходя из личного опыта, требований политики безопасности компании и уровня доверия к пользователям.

2.3 Файлы конфигурации .2.3.1 Конфигурация сервера.

Переносим из папки C:\Program Files\OpenVPN\sample-config в C:\Program Files\OpenVPN\config файл sample.ovpn. Переименовываем его в server.ovpn. Файл server.ovpn открываем на редактирование и приводим к следующему виду:

port 12345 proto udp dev tun dev-node "VPN Server" *dh* "*C*:\\Program Files\\OpenVPN\\ssl\\dh1024.pem" ca "C:\\Program Files\\OpenVPN\\ssl\\ca.crt" cert "C:\\Program Files\\OpenVPN\\ssl\\cert.crt" *key* "C:\\Program Files\\OpenVPN\\ssl\\cert.key" server 10.10.0.0 255.255.0.0 max-clients 32 keepalive 10 120 client-to-client comp-lzo persist-key persist-tun *cipher DES-CBC* status "C:\\Program Files\\OpenVPN\\log\\status.log" log "C:\\Program Files\\OpenVPN\\log\\openvpn.log" verb 4 mute 20

* где **port** — сетевой порт (12345 позволит избежать проблем при использовании Интернета в общественных местах, но может быть любым из свободных, например 1723, занятые порты в Windows можно посмотреть командой netstat -a);

dev-node — название сетевого интерфейса;

server — подсеть, в которой будут работать как сам сервер, так и подключённые к нему клиенты.

** так как в некоторых путях есть пробелы, параметр заносится в кавычках.

listen on? (optional)

;local a.b.c.d

Which TCP/UDP port should OpenVPN listen on?# If you want to run multiple OpenVPN instances# on the same machine, use a different port

number for each one. You will need to# open up this port on your firewall.# the default port 1194port 1194

TCP or UDP server? #Uncomment the line to enable TCP or UDP ;proto tcp proto udp

"dev tun" will create a routed IP tunnel, # "dev tap" will create an ethernet tunnel. # Use "dev tap0" if you are ethernet bridging # and have precreated a tap0 virtual interface # and bridged it with your ethernet interface. # If you want to control access policies # over the VPN, you must create firewall # rules for the the TUN/TAP interface. # On non-Windows systems, you can give # an explicit unit number, such as tun0. # On Windows, use "dev-node" for this. # On most systems, the VPN will not function # unless you partially or fully disable # the firewall for the TUN/TAP interface. **#Typically, dev tap is used if VPN server is # running on windows #tap is for Windows and tun is for Linux** dev tap ;dev tun

Windows needs the TAP-Win32 adapter name
from the Network Connections panel if you
have more than one. On XP SP2 or higher,
you may need to selectively disable the
Windows firewall for the TAP adapter.
Non-Windows systems usually don't need this.
;dev-node MyTap

SSL/TLS root certificate (ca), certificate
(cert), and private key (key). Each client

and the server must have their own cert and # key file. The server and all clients will # use the same ca file. # # See the "easy-rsa" directory for a series *#* of scripts for generating RSA certificates # and private keys. Remember to use # a unique Common Name for the server # and each of the client certificates. # # Any X509 key management system can be used. # OpenVPN can also use a PKCS #12 formatted key file # (see "pkcs12" directive in main page). #Please be sure the filename #ROOT CA is generated by build-ca, and it is used to verify the legality of customer certification. ca "C:\\Program Files\\OpenVPN\\config\\ca.crt" #The certificate file of server cert "C:\\Program Files\\OpenVPN\\config\\Cdtsmserver.crt" #The key of certificate file. key "C:\\Program Files\\OpenVPN\\config\\Cdtsmserver.key" # This file should be kept secret # Diffie hellman parameters. # Generate your own with: # openssl dhparam -out dh1024.pem 1024 # Substitute 2048 for 1024 if you are using # 2048 bit keys. dh dh1024.pem # Configure server mode and supply a VPN subnet

for OpenVPN to draw client addresses from.

ethernet bridging. See the man page for more info.

#Launch VPN server on TAP/TUN interface with Specific IP

The server will take 10.8.0.1 for itself,# the rest will be made available to clients.# Each client will be able to reach the server# on 10.8.0.1. Comment this line out if you are

address and net mask ;server 192.168.0.0 255.255.255.0

Maintain a record of client <-> virtual IP address # associations in this file. If OpenVPN goes down or # is restarted, reconnecting clients can be assigned # the same virtual IP address from the pool that was # previously assigned.

ifconfig-pool-persist ipp.txt

Configure server mode for ethernet bridging. # You must first use your OS's bridging capability # to bridge the TAP interface with the ethernet # NIC interface. Then you must manually set the # IP/netmask on the bridge interface, here we # assume 10.8.0.4/255.255.255.0. Finally we # must set aside an IP range in this subnet # (start=10.8.0.50 end=10.8.0.100) to allocate # to connecting clients. Leave this line commented # out unless you are ethernet bridging. #If users want to launch the VPN server on bridge server-bridge 10.8.0.2 255.255.255.0 10.8.0.50 10.8.0.100

Configure server mode for ethernet bridging
using a DHCP-proxy, where clients talk
to the OpenVPN server-side DHCP server
to receive their IP address allocation
and DNS server addresses. You must first use
your OS's bridging capability to bridge the TAP
interface with the ethernet NIC interface.
Note: this mode only works on clients (such as
Windows), where the client-side TAP adapter is
bound to a DHCP client.
;server-bridge

Push routes to the client to allow it # to reach other private subnets behind # the server. Remember that these # private subnets will also need # to know to route the OpenVPN client # address pool (10.8.0.0/255.255.255.0)
back to the OpenVPN server.
;push "route 192.168.35.0 255.255.255.0"
;push "route 192.168.20.0 255.255.255.0"

To assign specific IP addresses to specific
clients or if a connecting client has a private
subnet behind it that should also have VPN access,
use the subdirectory "ccd" for client-specific
configuration files (see man page for more info).

EXAMPLE: Suppose the client # having the certificate common name "Thelonious" # also has a small subnet behind his connecting # machine, such as 192.168.40.128/255.255.255.248. # First, uncomment out these lines: client-config-dir ccd ;route 192.168.40.128 255.255.255.248

Then create a file ccd/Thelonious with this line:
iroute 192.168.40.128 255.255.255.248
This will allow Thelonious' private subnet to
access the VPN. This example will only work
if you are routing, not bridging, i.e. you are
using "dev tun" and "server" directives.

EXAMPLE: Suppose you want to give # Thelonious a fixed VPN IP address of 10.9.0.1. # First uncomment out these lines: ;client-config-dir ccd ;route 10.9.0.0 255.255.255.252 # Then add this line to ccd/Thelonious: # ifconfig-push 10.9.0.1 10.9.0.2 # Suppose that you want to enable different # firewall access policies for different groups # of clients. There are two methods: # (1) Run multiple OpenVPN daemons, one for each # group, and firewall the TUN/TAP interface # for each group/daemon appropriately. # (2) (Advanced) Create a script to dynamically
modify the firewall in response to access
from different clients. See man
page for more info on learn-address script.
;learn-address ./script

If enabled, this directive will configure # all clients to redirect their default # network gateway through the VPN, causing # all IP traffic such as web browsing and # and DNS lookups to go through the VPN # (The OpenVPN server machine may need to NAT # or bridge the TUN/TAP interface to the internet # in order for this to work properly). ;push "redirect-gateway def1 bypass-dhcp"

Certain Windows-specific network settings # can be pushed to clients, such as DNS # or WINS server addresses. CAVEAT: # http://openvpn.net/faq.html#dhcpcaveats # The addresses below refer to the public # DNS servers provided by opendns.com. ;push "dhcp-option DNS 10.10.22.243" ;push "dhcp-option WINS 202.106.0.20"

Uncomment this directive to allow different # clients to be able to "see" each other. # By default, clients will only see the server. # To force clients to only see the server, you # will also need to appropriately firewall the # server's TUN/TAP interface. client-to-client

Uncomment this directive if multiple clients# might connect with the same certificate/key# files or common names. This is recommended# only for testing purposes. For production use,# each client should have its own certificate/key

pair.

#

IF YOU HAVE NOT GENERATED INDIVIDUAL

CERTIFICATE/KEY PAIRS FOR EACH CLIENT,

EACH HAVING ITS OWN UNIQUE "COMMON NAME",

UNCOMMENT THIS LINE OUT.

duplicate-cn

The keepalive directive causes ping-like

messages to be sent back and forth over

the link so that each side knows when

the other side has gone down.

Ping every 10 seconds, assume that remote

peer is down if no ping received during

a 120 second time period.

#(Openvpn can not connect again in mode server)

The value can be modified by users.

keepalive 10 120

For extra security beyond that provided # by SSL/TLS, create an "HMAC firewall"

to help block DoS attacks and UDP port flooding.

#

Generate with:

openvpn --genkey --secret ta.key

The server and each client must have

a copy of this key.

The second parameter should be '0'

on the server and '1' on the clients.

;tls-auth ta.key 0 # This file is secret

Select a cryptographic cipher.
This config item must be copied to
the client config file as well.
#We use DES-CBC as an example.
;cipher BF-CBC
;cipher AES-128-CBC
;cipher DES-EDE3-CBC
cipher DES-CBC

Enable compression on the VPN link. # If you enable it here, you must also # enable it in the client config file. ;comp-lzo no

The maximum number of concurrently connected
clients we want to allow.
The value can be modified by users.
max-clients 20

It's a good idea to reduce the OpenVPN
daemon's privileges after initialization
#
You can uncomment this out on
non-Windows systems.
;user nobody
;group nobody

The persist options will try to avoid # accessing certain resources on restart # that may no longer be accessible because # of the privilege downgrade. persist-key persist-tun

Output a short status file showing # current connections, truncated # and rewritten every minute. status openvpn-status.log

By default, log messages will go to the syslog (or # on Windows, if running as a service, they will go to # the "\Program Files\OpenVPN\log" directory). # Use log or log-append to override this default. # "log" will truncate the log file on OpenVPN startup, # while "log-append" will append to it. Use one # or the other (but not both).
;log openvpn.log
;log-append openvpn.log

Set the appropriate level of log
file verbosity.
#
0 is silent, except for fatal errors
4 is reasonable for general usage
5 and 6 can help to debug connection problems
9 is extremely verbose
#The value can be modified by users
verb 4

Silence repeating messages. At most 20# sequential messages of the same message# category will be output to the log.;mute 20

Примечание: комметарии отмечены «#» или «;». Данная конфигурация работает для OC Windows или Linux.

Помните, что в OC Windows для задания пути, необходимо использовать «\\» (например, "C:\\Program Files\\OpenVPN\\config\\foo.key")

2.3.2 Подключение к серверу OpenVPN.

В сетевых подключениях Windows открываем управление адаптерами
 ТАР-адаптер переименовываем в «VPN Server» (как у нас указано в конфигурационном файле, разделе dev-node):



VPN Server Сетевой кабель не подкл... TAP-Windows Adapter V9

- Открываем службы Windows и находим «OpenVpnService».



- Службу «**OpenVpnService**» настраиваем на автозапуск и включаем:

	Свойства: OpenVPN Service (Локальный компьютер) ×		
Службы (локалы ОрепVPI Останов Перезал	жб Общие Вход в систему Восстановление Зависимости Имя службы: OpenVPNService Отображаемое OpenVPN Service имя: Описание: Исполняемый файл: "C:\Program Files\OpenVPN\bin\openvpnserv.exe" Тип запуска: Автоматически Состояние: Выполняется Запустить Остановить Приостановить Продолжить	Состояние Выполняется Выполняется Выполняется Выполняется Выполняется Выполняется	Тип запуска Вручную (ак Вручную (ак Автоматиче Вручную Автоматиче Автоматиче Автоматиче Вручную (ак Вручную (ак Вручную
	Вы можете указать параметры запуска, применяемые при запуске службы из этого диалогового окна. Параметры запуска: ОК Отмена Применить	Выполняется Выполняется Выполняется	Автоматиче Вручную Вручную Вручную Автоматиче Вручную

- Ранее переименованный сетевой интерфейс должен включиться:



2.3.3 Конфигурация клиента.

Переходим в папку **C:\Program Files\OpenVPN\sample-config**. Открываем и редактируем файл **client.ovpn.**

On Windows, you might want to rename this # # file so it has a .ovpn extension # # Specify that we are a client and that we # will be pulling certain config file directives # from the server. Client # Use the same setting as you are using on # the server. # On most systems, the VPN will not function # unless you partially or fully disable # the firewall for the TUN/TAP interface. #we use Tap as an example dev tap :dev tun # Windows needs the TAP-Win32 adapter name # from the Network Connections panel # if you have more than one. On XP SP2, # you may need to disable the firewall # for the TAP adapter. ;dev-node MyTap # Are we connecting to a TCP or # UDP server? Use the same setting as # on the server. #Please be same as the server's protocol. ;proto tcp proto udp # The hostname/IP and port of the server. # You can have multiple remote entries # to load balance between the servers.

remote 192.168.35.91 1194 ;remote my-server-2 1194

#Outer network ip of OpenVPN

Choose a random host from the remote

list for load-balancing. Otherwise
try hosts in the order specified.
;remote-random

Keep trying indefinitely to resolve the
host name of the OpenVPN server. Very useful
on machines which are not permanently connected
to the internet such as laptops.
resolv-retry infinite

Most clients don't need to bind to# a specific local port number.Nobind

Downgrade privileges after initialization (non-Windows only)
;user nobody
;group nobody
Try to preserve some state across restarts.
persist-key
persist-tun

If you are connecting through an # HTTP proxy to reach the actual OpenVPN # server, put the proxy server/IP and # port number here. See the man page # if your proxy server requires # authentication. ;http-proxy-retry # retry on connection failures ;http-proxy [proxy server] [proxy port #]

Wireless networks often produce a lot# of duplicate packets. Set this flag# to silence duplicate packet warnings.;mute-replay-warnings

See the server config file for more # description. It's best to use # a separate .crt/.key file pair # for each client. A single ca # file can be used for all clients. #Please be sure the file name ca /config/openvpn/ca.crt cert /config/openvpn/Client.crt key /config/openvpn/Client.key

Verify server certificate by checking # that the certicate has the nsCertType # field set to "server". This is an # important precaution to protect against # a potential attack discussed here: # http://openvpn.net/howto.html#mitm # # To use this feature, you will need to generate # your server certificates with the nsCertType # field set to "server". The build-key-server # script in the easy-rsa folder will do this.

ns-cert-type server

If a tls-auth key is used on the server# then every client must also have the key.;tls-auth ta.key 1

Select a cryptographic cipher.
If the cipher option is used on the server
then you must also specify it here.
;cipher x
we use DES-CBC as an example
cipher DES-CBC

Enable compression on the VPN link. # Don't enable this unless it is also # enabled in the server config file. ;comp-lzo no # Set log file verbosity. **verb 3**

Silence repeating messages
;mute 20

2.3.4 Создание файла client.tar

Для создание клиентского файла необходимо:

- Скопировать файл client.ovpn из C:\Program Files\OpenVPN\sample-config и Client.crt, Client.key, ca.crt файлов C:\Program Files\OpenVPN\easy-rsa\ и C:\Program Files\OpenVPN\ для клиента.
- Переименовать файл client.ovpn в vpn.conf.
- Файл vpn.conf привести к следующему виду, соблюдая весь синтаксис:

client resolv-retry infinite nobind remote 172.31.71.94 12345 proto udp dev tun comp-lzo ca /config/openvpn/ca.crt *cert /config/openvpn/clients.crt key /config/openvpn/clients.key dh* /config/openvpn/dh1024.pem float cipher DES-CBC keepalive 10 120 persist-key persist-tun verb 0

- При помощи программы 7-zip для создать файл **vpn.tar.**

3. Настройка телефона 3.1 Конфигурация через web

В разделе **Network-Advanced-VPN**:

- Устанавливаем маркер напротив функции **OpenVPN**
- Включаем данный функционал

Active	Enabled 🔹
User Name	
Password	•••••
Upload(<50K)	Выберите файл vpn.tar

- Загружаем созданный файл vpn.tar
- Нажимаем клавишу «Upload»
- После успешной загрузки загрузки появится сообщение:



- Активируем **OpenVPN** и нажимаем кнопку «Submit»
- После перезагрузки аппарат применит настройки и при успешном

подключения VPN-сервера на дисплее отобразится значок



Через экранной меню можно увидеть присвоенный ір адрес.

